

System Requirements:

Supported Operating Systems:

Microsoft® Windows® 2000, NT, XP. (NT 4.0 requires Service Pack 6a)

NOTE: Bio-Pen Software requires Windows updates of newer than .NET Framework 2.0 or higher and MDAC 2.6 before installing software.

If an error message appears during the software installation, exit the installation, update MDAC and/or .NET Framework and then retry.

Bio-Pen Software Installation Guide

To install

To be able to use your Bio-Pen, you must first install the **LogBook** and **LockBox** software. To install the programs, follow these simple steps:

- Go to <http://www.bio-pen.com/page/Downloads.htm>
- In the **LogBook** window, click **Download Now**



- Save the file to any location on your hard drive
- Once downloaded, double click the **Setup.exe** icon
- When the **Setup Wizard** opens, click **Next**
- Check that **Installation Folder** is set as **C:\Program Files\Bio-Pen**
- Click **Next** to confirm the installation
- When installation is complete, click **Close**
- To install **LockBox**, click **Download Now** and follow the instructions above